

Sparrow Trap Door Trap Instructions For Use



The Sparrow Trap Door Trap is a professional trap intended for the removal and relocation of birds trapped indoors. Birds are captured when they land on the perch. They remain quiet in the holding box until they can be safely released. *Caution: the trap is under spring tension so keep hands and fingers away from perch, lid and platform. Use extra care when mounting above floor level so trap does not fall or topple onto someone. Keep out of reach of pets and children.*

To set the trap



1. Open lid by grasping near front of trap and swinging open so the feeding panel is horizontal.



2. Keeping hands clear of lid when in the open position - secure lid open with front wire link.



3. While holding front link with left hand adjust perch link at rear of trap and align with tab at end of front link.

4. Fine tune the perch tab trip mechanism as shown in the photos below.



Too sensitive



Over engaged



Ideal setting

5. Carefully place a small piece of bread or other bait at the rear of baffle like shown. Sparrows prefer bread and its use will help keep the trap and area around the trap clean.



6. Place trap on a solid surface near where birds are known to congregate and within their line of sight. You may need to experiment to find the best location.

After a bird is captured do not lift lid to confirm it is in the trap or it will escape! Bird will remain calm inside trap. Take outdoors and release bird by opening lid or bottom cleanout panel.

Optional Sparrow Call

The sparrow call sound module is unique feature of the Sparrow Trap Door that is proven to significantly increase the effectiveness of the trap. The call module contains nine call presets such as constant calling, intermittent, volume level and timed. Toggle through each program by pressing the round button in front. Preset descriptions below. *Caution – use caution adjusting sound module while it is attached to trap or when trap is set.*

Mount the sound module by lining up the Velcro attachments (and the front button) on the module with the appropriate mates on the trap, then, grasping the top of the baffle, firmly press the module in place.

Power switch



Power the module on by sliding the black switch to the up (ON) position.

Use the function button to cycle through the available programs. The programs are listed in order as follows (press once for 1, twice for 2, three times for 3, etc.):

- 1 – Continuous call higher volume
- 2 - Continuous call lower volume
- 3 - 4 minute call every hour
- 4 - 15 minute call every 3 hours
- 5 - 1 hour per day call - hour-long call followed by 23 hours silence. Repeats daily.
- 6 - 1 hour per day call - hour-long call followed by 23 hours silence. Lower volume. Repeats daily.
- 7 - Delayed start 23-hour silence followed by 1-hour call. Start at 8 am or later. Repeats daily.
- 8 - Delayed start Continuous call - 20-minute silence followed by continuous call.
- 9 - Delayed start 4-minute call every hour
- 10 - A repeating tone indicates you have reached the end. Cycle power on/off or press button to return to preset number 1.



Function button

All calls are proven to be effective. Delayed start calls are good for birds already inside a building. The delay allows you time to set the trap in place before calling begins. Calls 2, 3, and 4 are useful for discrete operation when no birds are currently present. Batteries can last over 5-7 days constant calling.

Power – Includes three AA batteries.

Plug-in option. A plug and 10 ft. power cord is available separately.