




One row of Flex-Track can protect the same width ledge as multiple rows of other products. Labor and material are therefore much less. Often just one row on the outer edge is enough.



Double-sided ledges



Anti-water damming pads stuck every 12 inches will allow water to flow under the track

10 pads are included with each roll of track.



STRAIGHT QUICK CONNECTORS

Fast and easy to install, attractive and ultra durable. Saves labor time and provides for a long-lasting installation. Use two Straight Connectors to jump power from track to track.



CORNER QUICK CONNECTORS

This connector Is revolutionary. It is low profile and features copper conductors over the entire surface. Straight cut the track, lay it inside the connector and snap the durable top down for an attractive connection.

(10 Pack) · BS-Q07



"T" QUICK CONNECTORS

Many jobs require time consuming T?s. Now those can be done just as quickly as straight and corner connections. By cutting the small top fins the part also hinges up and down..



projects need more connections. These addition to the standard set that comes with the flex-track.

GRAY

STANDARD CONNECTORS

& LEAD OUT WIRE

50 ft · S-LW15 250 ft. · BS-LW70





FLEX TRACK LEAD-OUT WIRE

Twisted copper, 14 gauge double wire is easy to cut, strip & crimp.



DELUXE WIRE STRIPPING TOOL

This elegant tool easily strips wires, completely. It grabs, cuts and pulls the wire, you just squeeze. Use the #10 or #8 opening.

CONNECTOR CRIMP TOOL Solid connections are a must for a long-

TO-Q15

perfect crimp.

TO-Q20

WARNING SIGNS

Bold, plastic warning labels should be placed prominently. Glue or screw to the ledge or side of the building. 10/pack.

10 Units · BS-WL10

LEAD WIRE GUIDES - 100

New, smaller and black for a less visible, tighter job.

100 Units · BS-LW45



Bird Barrier Bond or 6100 should be used to secure Bird-Shock Flex-Track to clean surfaces. A 10.2 oz. tube secures 30 - 35 ft. of track.

Bird Barrier Bond 10.2 oz. (ea.) HA-BB03 Five-Year Guarantee

E6100 Clear 10.2 oz. (ea.) HA-BB04 One-Year Guarantee







POWER ACCESSORIES

DIGITAL VOLTAGE TESTER

Make sure your system is sending the correct amount of electricity. Tester reads in 1,000-volt increments

POWER INDICATOR

Attach these to the track and the building. Flashing indicates the system is functioning properly. Can be seen from distance at night. BS-TD10



Chargers

BATTERY TRICKLE CHARGER

Charge Solar Charger batteries quickly or during extended periods of cloudy weather.

BS-TE30

Powers

500 ft.

STANDARD & LARGE **CHARGERS**



110V SMALL CHARGER

UL Approved, this intermittent charger powers up to 1,000 feet of Bird-Shock. Mount indoors in dry space. Flashing light indicates functionality of the system.

Input: 110-120 VAC, 60 Hz, 1VA Output: 6,350 V (Unloaded), 730 V @ 500 ohm Load Output Joules: 0.1

Small 110V Charger · BS-CP00



Input: 4V DC Output (max): 8kV (+/-) 20% Output Pulse Width at 500 Ohms: 50uS Output at 100 Ohms: 3.5A

Small 4V Solar Charger · BS-CS00



Powers 300 ft

Replacement Battery · BS-CS05



Small 120V Plug-In Charger · BS-CP30

SMALL 120V PLUG-IN CHARGER

Weatherproof, can be mounted outside (but make sure the plug itself is in a

Input: 120 VAC Output (max): 9kV +/- 10% Output Pulse Width at 500 Ohms: 100 uS

weatherproof housing).

Ideal for smaller projects. Features connectors on the bottom and an on/off switch.

Input: 12V DC Output (max): 8.6kV +/- 10%
Output Pulse Width at 500 Ohms: 25uS Output at 500 Ohms: 4.0kV, 0.14J ATTACH BATTERY LEADS AND

Small 12V Solar Charger · BS-CS30 Replacement Battery · BS-CS25



6V/12V BATTERY CHARGER

Ideal for small jobs that cannot be plugged into mains, or are in the shade (where solar will not charge). This charger functions with a 6 or 12 volt rechargeable battery (sold separately). The battery must be secured to the tree or structure. A flashing light confirms the charger is functioning properly.

Output: 7.3 Kv

6V/12V Battery Charger · BS-CS15 6V Battery · BS-CS17 12v Battery · BS-CS18



LARGE BIRDS / LARGE JOBS

These powerful chargers are capable of handling large runs of Flex-Track. They require specific installation methods and the use of a digital track tester. NOTE: Installation of these units without regard to the installation instructions can result in visible and audible arcing or sparking. Please use appropriate care and call our specialists for job-specific recommendations.

LARGE 120V PLUG-IN CHARGER

This charger is weatherproof, but must be plugged into a weatherproof receptacle. It features a blinking indicator light when operating. Powerful enough for most jobs.

> Input: 120 Vac Output (max): 8.8kV +/- 10% Output at 500 Ohms: 5.6kV, 1.3J

> > Charger BS-CP25



LARGE 12V SOLAR CHARGER

This solar powerhouse delivers plenty of shock and can be installed anywhere that gets several hours of sunlight every day.

Input: 12Vdc Output (max): 8.6kV (+/-) 10% Output Pulse Width at 5000hms: 25uS Output at 500 Ohms: 5.4kV, 0.33J

Large 12V Solar Charger- BS-CP25 Replacement Battery - BS-CS25



